

HEAT STRESS SURVEY SHEET

HEAT STRESS SURVEY SHEET

DATE: _____

STATION	TIME	DB HANGING	DB	WB	GT	WBGT	ROUTINE ⁽²⁾ CURVE/LIMIT	NON-ROUTINE CURVE/LIMIT	DRILLS CURVE/LIMIT	HEAVY WORK CURVE/LIMIT
BTOW							II =	III =	III =	VI =
Upper Level (Checks)							II =	III =	III =	VI =
Lower Level							II =	III =	II =	VI =
MFP Watch							II =	III =	III =	VI =
Burnerman							II =	III =	III =	VI =
Messenger ⁽¹⁾							III =	IV =	IV =	VI =
Engineroom Console Booth 2)							I =	I =	I =	VI =
Throttle							I =	I =	I =	VI =
EMOW							I =	I =	I =	VI =
Evaporators							I =	II =	II =	VI =
Upper Level							II =	III =	III =	VI =
Lower Level							II =	III =	III =	VI =
Messenger (1) 3)							III =	IV =	IV =	VI =
3)										
Laundry Press Area							III =	NA =	NA	VI =
Driers							III =	NA =	NA	VI =
Scullery							V =	NA =	NA	VI =
Galley							II =	NA =	NA	VI =
Serving Line							II =	NA =	NA	VI =

OPNAV 5100/17 (Rev. 5-99)

NOTE: (1) Messenger stay times should be determined by taking the average of all WBGT Index values for the space not including the console booth.

NOTE: (2) Only the column that pertains to the current watch/work situation needs to be completed (e.g. all four columns do not need to be filled in).